

WARNING: Please be very cautious before starting the unloading process. Odino has 500kg, and please make sure that only the person knowing what is doing handles the product! Any other way is not allowed to unload the product!

Step 1

Fix the *Lifting eye nuts* you received in the package.



Step 2

Insert one *D shackle* on each side and position the *Ratchet strap* like it is shown in the picture.



Step 3

Remove all boards, except ones where is written **DO NOT REMOVE!**



Step 4

Once you removed all marked boards, you can start lifting the shower. Use a truck with a crane for doing that. Be very careful! The shower needs to be on the pallet the whole time until is upright. After that, lift the shower from the pallet and place it on the floor, making sure that you don't do any damage to the stone.

HERE YOU CAN FIND A VIDEO ON HOW TO DO IT:

<https://drive.google.com/drive/folders/1TzyHiAEdictmvZDdftpPnS8gzKWbb2W6?usp=sharing>